


HANDLES & BUTTONS



CHROME


PARK PIN LEVER HANDLES

CHROME PKCLHBCP




PARK CROSS HANDLES

CHROME PKCHBCP




PARK FLARED LEVER HANDLES

CHROME PKCFHBCP




FUSION CROSS HANDLES

CHROME FUHBCP




FUSION LEVER HANDLES

CHROME FULHBCP



AURORA STAR HANDLES

CHROME AUSHBCP



MERINO CROSS HANDLES

CHROME MHBCP



MERINO LEVER HANDLES

CHROME MLHBCP




HANDLES & BUTTONS



CHROME


MERINO FLARED LEVER HANDLES

CHROME MFLHBCP




SOUTHERN CROSS HANDLES

CHROME SXHBCP




DORSET CROSS HANDLES

CHROME DHBCP



DORSET LEVER HANDLES

CHROME DLHBCP



EASY CLEAN CROSS HANDLES


CHROME ECHB

COLD ONLY CHROME ECHB1C

HOT ONLY CHROME ECHB1H


WARM ONLY CHROME ECBHW

RAIN WATER ONLY CHROME ECHBRW




EASY CLEAN LEVER HANDLES

CHROME ECLHBHC



EASY CLEAN FLARED LEVER HANDLES


CHROME ECFLHB



ANTI VANDAL HANDLES

CROSS - CHROME ECVHB

LEVER - CHROME ECVLHBC



GRUB SCREW LOCATES IN GROOVED BUTTON TO PREVENT REMOVAL OF BUTTON AND HANDLE